



ATRIX OMEGA PLUS TYPE H ASBESTOS VACUUM

As with all electrical equipment, care and attention must be exercised at all times during use, in addition to ensuring that routine and preventative maintenance is carried out periodically to ensure safe operation, failure to carry out maintenance as necessary, including the replacement of parts to the correct standard could render this equipment unsafe and the manufacturer can accept no responsibility in this respect.

CAUTION

This appliance contains dust hazardous to health, emptying and maintenance operations, including the removal of the dust collection means must only be carried out by authorised personnel, wearing suitable personal protection. Do not operate without the full filtration system fitted. Do not use this machine for the collection of explosive dusts.

NOTE

This machine is for "DRY USE ONLY" and must not be stored outside or used in wet conditions - Failure to follow this instruction will invalidate your warranty.

THE FOLLOWING PRECAUTIONS MUST BE REGARDED AT ALL TIMES.

- Before use operators should be referred to the applicable safety regulations currently in force in the country of operation which are appropriate to the materials being handled.
- Before use operators should be provided with information, instruction and training of the use of the appliance and the substances for which it is to be used, including the safe removal and disposal of the material being collected.
- Before use operators must carry out a visual inspection of the case, plug, and cable. Do not use if anything is found to be damaged.
- This appliance is intended for shadow vacuuming methods only; failure to use this appliance for its intended use will reduce the life of the filter cartridge.
- If this appliance is used in a contaminated area, the outside of the appliance should be decontaminated by vacuum cleaning methods, blanking caps replaced and wiped clean with an adhesive wipe. All the appliance parts including accessories shall be regarded as contaminated when removed from the hazardous area and appropriate action shall be taken to prevent dust dispersal.
- This appliance is fitted with a low flow indicator to show the airflow has reduced.

WHEN LOW FLOW INDICATOR FLASHES

The unit is fitted with a low flow warning indicator to show when the airflow is too low - It is located next to the ON/OFF switch.

Is the hose blocked?

Unblock the hose.

Is the filter cartridge full?

Return to whole vacuum back to your DOP Testing/Asbestos Disposal company for the filter cartridge to be replaced, and the appliance re-tested and cleaned.

THIS APPLIANCE MUST HAVE A FILTER INTEGRITY TEST (DOP) AT 6 MONTHLY INTERVALS, OR WHEN THE FILTER CARTRIDGE HAS BEEN REPLACED, OR IF THE APPLIANCE HAS BEEN DROPPED.

THIS NEEDS TO BE PERFORMED BY AN APPROVED TESTING COMPANY.